

PREEMIE T-SHIRT WITH SET-IN SLEEVES



Supplies:

Cotton knit fabric
Ribbing
Thread

Directions:

Cut 2 – 2 1/2" x 5" ribbing for short sleeves or 2 1/2" x 4" for long sleeves

Cut 1 – 2 1/2" x 9" ribbing for neck

1. Sew one shoulder seam.
2. Fold neck ribbing lengthwise. Divide into four sections and mark with three pins.
3. Divide the neck into four sections and mark with three pins.
4. Match ribbing and neck pins and pin to the right side of the neck.
5. Sew ribbing to neck.
6. Sew the shoulder seam.
7. If using ribbing on the bottom of sleeve follow instruction in step 2, 3, 4 and 5. Otherwise, press sleeve bottom up 5/8" and sew in place.
8. Sew sleeves to the body matching notches.
9. Sew side seams and out the sleeve.
10. Press up 5/8" hem on bottom of shirt and sew in place.

NECK
RIBBING
2 1/2" x 9"


PREEMIE
T-SHIRT
WITH SET-IN
SLEEVE


FRONT
CUT 1

FOLD

STRETCH

HEM 5/8"






CENTER

PREEMIE T-SHIRT
WITH SET-IN SLEEVE
CUT 2

← STRETCH →
SHORT SLEEVE RIBBING 2 1/2" x 4 1/2"

--- CUT HERE FOR SHORT SLEEVES ---

LONG SLEEVE RIBBING 2 1/2" x 4"



PREEMIE
T-SHIRT
WITH SET-IN
SLEEVES

BACK
CUT 1

FOLD

STRETCH