

PREEMIE BOOTIES

Supplies:

Fabric – stretch knit or stretch fleece

Ribbing – 2 pieces 3 1/2" x 4 1/2" for cuffs

Directions:

1/4" seam allowance

1. Fold ribbing in half widthwise to find the center of the ribbing. Fold ribbing in half lengthwise. With raw edges together match center of ribbing with center of bootie top and ends of ribbing with ends of bootie.
2. With right sides together, sew or serge ribbing to the bootie starting at the back and stretching ribbing to fit.
3. Matching the notches, sew back seam of bootie together going through the ribbing.
4. With right sides together, match notches on bootie top with sole and back seam with center back of sole.
5. Sew the sole to the bootie.



